

# PORTO Underbasin Cabinet

<p>1 tap hole 1 drain hole</p> <p>Y = 600-800-1000mm</p> <p>M = 1/2</p>	<p>2 tap holes 2 drain holes</p>	<p>8mm 6x 6x 2x 2x</p>	<p>1</p> <p>W = 600/800/1000/1200mm X = Washbasin height</p> <p>900mm</p> <p>W-124 W-60</p>
<p>2</p> <p>4x</p> <p>ø8mm</p>	<p>3</p>	<p>4</p>	
<p>5</p>	<p>6</p> <p>ø8mm 2x</p>	<p>7</p>	
<p>8</p> <p>When fronts are tilted forward. If not, skip this step.</p>	<p>9</p> <p>Runner Type 1 Runner Type 2 Runner Type 3</p> <p>1. Vertical adjustment. 2. Horizontal adjustment. 3. Fixation. 4. Remove front panel.</p>		